



PARTNER
IN VENTILATION
2VV.CZ

EN

AirGENIO^{2VW} SUPERIOR



Operation instructions

CE EAC

1. CONTROL

READ CAREFULLY!

Before the initial commissioning, check:


- that the device is well fastened to the support structure,
- that the device is properly closed
- that the power supply is properly connected, including the earthing and the external trigger protection,
- that all the electrical components are securely connected,
- that the installation complies with all the instructions herein,
- that no tool or any other object that may damage the unit remains within.

CAUTION!

- Interventions or changes to the internal connections are forbidden and shall result in the loss of warranty.
- We recommend the use of accessories supplied by our company. Contact your supplier in case of doubts regarding the use of non-original accessories.


START-UP

After connecting power supply, the display lights up and the data is loaded. The device is ready to be activated once the service data has fully loaded.




The remote control has a touch screen. The device is controlled tapping the symbols on the screen

Description of main screen




Warning icons

They inform about errors. Clicking on them opens a screen with the error report.



Information icons

They only inform about status, not errors.



1. CONTROL



Current status

This screen shows the detailed status of the opening and the sensor values:

- Current air-flow settings (step or %), information icons
- Air temperature at intake*, exhaust*, room temperature* and outside temperature* (* – if the relevant sensors are installed and enabled)
- Heater output settings (if included)

Labels for the Current status screen:

- Outside temperature: 16°C
- Inlet temperature: 20°C
- Room temperature: 22°C
- Heat power: 50%
- Fan speed: 80%
- SP= Temperature setpoint: 45°C
- Return water temperature: 18°C
- Green color = active sensor
- Indicates heating is blocked (summer mode)
- Info button
- Back to previous screen button

The information on any connected SLAVE units will be shown here. It can be accessed moving the screen upwards.



Slave units screen showing:

- Sub 3: 0% 10%, W:30°C, 20°C
- Sub 4: 10% 20%, W:31°C, 21°C
- Sub 5: Off, 50%
- Sub 6: 30% 40%, W:33°C, 23°C

The settings can be found below, under "SUBUNITS"



Settings MENU

Labels for the Settings menu screen:

- Display backlight
- Language
- Date and time
- Air flow settings (with closed doors)
- Required temperature settings (with closed doors)
- AirGENIO app
- Back to previous screen
- QR code
- Parameters



Required temperature settings with closed doors

Labels for the Required temperature settings screen:

- Actual temperature at selected sensor in menu 09: 21°C
- Reduce or increase required temperature: 23°C
- Required output: Manual mode = %, Automatic mode = °C
- Confirm + return

If the heating is blocked in summer mode (MENU - SUMMER HEATING), the screen will show a "Sun" icon and will not allow to select the output.



Air flow settings with closed doors

Labels for the Air flow settings screen:

- Display required air flow (20% steps)
- Display the current air flow status: 80%
- Reduce or increase opening's air flow (with closed doors): 20%
- Confirm + return



Date and time settings

Labels for the Date and time settings screen:

- Current date and time: 08 03 28 02 2017
- Confirm + return
- Back to main screen

1. CONTROL



Timer

Unless otherwise set, the unit goes on stand-by mode after the timer expires.

Activate/deactivate timer

Weekly mode

Annual mode

Confirm + return

Back to main screen

Weekly mode

Tap on a day to set different time modes

Button to copy the day plan to another day

Tap on a day to set different time modes

Button to copy the day plan to another day

Copy + return

Copy to

Annual mode

START / STOP interval

Start 14 / 03

Stop 24 / 03

0% 0°C

CANCEL

Tap to add a new time mode

Tap to add a new time mode

Off mode

Only MANUAL

Fan 20%

Required ventilation rate in manual mode

Temperature 0°C

Required heating rate in manual mode



Language

There are 5 languages available

Select language

Confirm + return

Back to main screen

Confirmation of selection



Lightning settings

On mode

Lightning level on stand-by

Display backlight when on

Standby

Confirm + return

Back to main screen

1. CONTROL



AirGENIO App





QR code for downloading the AirGENIO application for smart devices

Pairing mobile device with unit using QR code.



Pairing smart device:

The IP address and PIN of the unit can be entered manually or by using a QR code for quick pairing of the unit.

1. Pairing using QR code:



2. Manual pairing:




1. CONTROL



Service menu

Enter code 1616 to access the service menu




Delete/return

Access menu

1616




Choose this menu after centring the screen and tapping on enter.



Access selected menu

MENU - MODE



MANUAL control


Activate/deactivate automatic control of motor speed according to temperature

Setting AUTO or MANUAL may block/unblock certain items in the service menu.

MENU - HW SETTING



Use this menu to set the detailed behaviour of the inputs and outputs of the regulators



Ad 1) - External temperature sensor activation/settings Options:
None - no sensor connected - inactive
EXT-1 (45,46) - sensor connected (must be on terminals 45 y 46)
BMS - sensor active and used from the master system

Ad 2) - Sets the external contact input behaviour. Options:
None - inactive
External control - External switching of device
Night reduction - Night reduction on/off (settings described below)

Ad 3) - Thermostat (NO/NC)

MENU - FILTER TIMER



Use this menu to set the period (in motor hours) after which you will be reminded to replace the filters or reset to timer.




Set the time after which a notice will appear in the main screen.

1000h ~ 5000h

Current timer status

RESET button (use after replacing filters)

Shows the status of the clogged filter in the main screen




MENU - TEMPERATURE SENSOR




Available only in automatic mode

Use this menu to select the sensor to be used for primary temperature control



Only available in Manual mode.




Options:

Outlet - Temperature sensor at the outlet (behind the exchanger)
Inlet - Temperature sensor at the inlet (before the exchanger)
Room - Room temperature sensor
Thermostat - Room thermostat (ON/OFF)
Room BMS - Room temperature sensor from master system

1. CONTROL

MENU - OUTLET TEMP LIMITS

Use this menu to set the limits of the exhaust



If "OUTLET" is selected in the TEMPERATURE SENSOR MENU, it will not be possible to set values as they are already defined by the sensor. You will see this screen:



MENU - MODBUS RTU


Use this menu to set the Modbus RTU communication parameters



An incorrect setting may prevent communication with the regulator

MENU - NETWORK


Use this menu to set the communication parameters of the network interface



An incorrect setting may prevent communication with the regulator

MENU - USER LOCK

Use this menu to set the limits to control the regulator with a multi-level panel



Options:

None – Limit inactive

On/Off – Only On/Off and access to the information menu are enabled in the main screen

On/Off, Temp, Flow – On/Off, the information menu, and temperature and air flow settings can be accessed without password.

Full – Only the information menu can be accessed without password

User mode – Special user mode, see image below

MENU - SUMMER HEATING

Use this menu to set heating limits in summer months



If the outside temperature sensor is not set, the "summer heating" mode will operate only according to the selected time and the temperature will not be taken into account

MENU - Night Reduction

This MENU allows for setting reduced temperatures during night hours with closed doors.



Setting reduced temperature range -1~-5°C

In this menu, the reduction of temperature may be set only by five degrees at the set time compared to the set (required) temperature.

1. CONTROL

MENU - DOOR CONTACT

This MENU allows for setting the behaviour of the regulator according to doors contact

Zapnutí/vypnutí této funkce

Mode:
Fixed - fixed setting
Selflearning - automation menu

Setting Fixed mode

Time interval

Blower power with open doors

Required temperature with open doors

Suspend mode:
at a set time, or upon achieving a specific temperature

Time of shutter operation per minimum rotation of the motor from closed doors.

Time of shutter operation per maximum rotation of the motor from closed doors.

Temperature

Blower power with open doors.

The temperature the shutter attempts to reach with open doors.

Room
Outlet
Inlet
Room
Thermostat
Room BMS

In this menu it is possible to specify which sensor will be active and the temperature the shutter will attempt to reach after closing doors so as to balance temperature loss. After reaching the set temperature, the shutter transitions into the selected automatic/manual mode.

MENU - DOOR CONTACT

MENU Selflearning



Selflearning- available only in automation and active function mode (Auto speed control), depending on the number of open doors it optimises the period in which the shutter is in operation, even when doors are closed.

Must be set to activate Selflearning.



MENU - WATER ANTIFREEZE

The menu is enabled only in units with water exchanger


Settings (20%-100%)

Ventilation rate with open doors (20%-100%)


1. CONTROL

MENU - SUBUNITS

Use this menu to set the behaviour of the IC-S regulators connected as SLAVE



Slave address parameter:




ADDRESS	SLAVE UNIT	ADDRESS	SLAVE UNIT
1	1	6	6
2	2	7	7
3	3	8	8
4	4	9	9
5	5	A	10

Ad 1) – Use one door contact as main. Its status will be sent to the SLAVE regulators and it will no longer be necessary to connect it to each regulator, if required.

- Not allowed = the door contact will not transmit to the SLAVE regulator from the MASTER
- Allowed = the door contact will transmit to the SLAVE regulator from the MASTER

Ad 2) – Activates in the main screen the icon to turn each SLAVE regulator ON/OFF. If inactive, all the SLAVE regulators will be turned on or off simultaneously


- Not allowed = The SLAVE regulators are turned on/off simultaneously
- Allowed = The SLAVE regulators can be turned on/off individually from the main screen



MENU - Adv. WATER SETTING




This MENU is available only for units with water heat exchanger it allows for advanced setting of water heat exchanger regulation.



MENU - Adv. fan setting

The MENU for setting the blowers when closing and opening doors. It allows for advanced settings of blower control.

The time for which the blower will be operational from the moment the desired temperature is achieved +0.3°C on the ROOM sensor in closed door mode. This setting is available only when the ROOM regulation sensor is selected (1616/Temperature sensor)



The set limits on blower power restrict the extent of blower control for open and closed doors. This restriction is applied to manual and automatic control of blower power. Exceeding limits in any blower power setting is signalled when the setting element turns red with the text overruns.

2. MALFUNCTIONS

2.1 MALFUNCTIONS

Disconnect the main power supply before any intervention to the unit. If you are not sure of the correct steps, do not attempt to perform any repairs and call a professional service!

Description	Unit behaviour	Likely problem	Solution
44 – Fan error	Unit out of order	Overheated fan or defect on thermal contact of inlet fan	Determine the cause of the overheating (defective bearing, short-circuit...) or replace the motor. Check the thermal contacts from the motor to the regulator.
45 – Mandatory maintenance/filter clogged	Unit operational	Filter clogged or the time to replace it has come	Replace filters. After replacing, do not forget to reset the MENU 1616 – FILTER TIMER
46 – Heater malfunction	Unit out of order	Heater malfunction	Check the heater and the condition of the safety thermostat Does the heater have proper cooling? Check engine running.
47 - malfunction in external temperature sensor (45,46)	Unit out of order	Temperature sensor malfunction on terminals 45,46	Check that the sensor is correctly connected to the electronics or test it measuring its resistance (the resistance value at +20°C is around 10kΩ)
48 – Outlet temperature sensor malfunction (49,50)	Unit out of order	Temperature sensor malfunction on terminals 49,50	Check that the sensor is correctly connected to the electronics or test it measuring its resistance (the resistance value at +20°C is around 10kΩ)
49 – Inlet temperature sensor malfunction (51,52)	Unit out of order	Temperature sensor malfunction on terminals 51,52	Check that the sensor is correctly connected to the electronics or test it measuring its resistance (the resistance value at +20°C is around 10kΩ)
60 – Exchanger's return sensor malfunction (53,54)	Unit out of order	Temperature sensor malfunction on terminals 53,54	Check that the sensor is correctly connected to the electronics or test it measuring its resistance (the resistance value at +20°C is around 10kΩ)
61 – Room temperature sensor malfunction (55,56)	Unit out of order	Temperature sensor malfunction on terminals 55,56	Check that the sensor is correctly connected to the electronics or test it measuring its resistance (the resistance value at +20°C is around 10kΩ)
62 - malfunction in external temperature sensor from BMS	Limited operation of the device	Temperature sensor malfunction in BMS	Check that in the BMS that the address where the sensors sends the data is properly set (on the right regulator) Check the function of the sensor in the BMS
63 - malfunction in room temperature sensor from BMS	Limited operation of the device	Temperature sensor malfunction in BMS	Check that in the BMS that the address where the sensors sends the data is properly set (on the right regulator) Check the function of the sensor in the BMS
79 – Heating reduced due to low air flow	Unit operational	Only information	The air flow settings were reduced, limiting the heater output to prevent overheating
65 – Communication error	Unit out of order	Communication error	Check the communication cable for damages and if it is properly connected Observe the wiring diagram to prevent occurrences that may disrupt communication (wiring near high tension, phenomena on site causing disruptions)
Unit's not working	Unit out of order	Power supply interrupted	Check that the power supply is not interrupted
		Cracked fuse	Check the fuse in side the control module
The heating switches off automatically	Unit operational but not heating	The heater overheats	The heater overheats due to insufficient air flow. Check that the ventilators are in good order and that the air supply is not disrupted.

3. CONCLUSION

3.1 CONCLUSION

In case of any doubt or query, do not hesitate to contact our sales or technical support departments.



2VV, s.r.o.
Fáblovka 568
533 52 Pardubice
Czech Republic



+420 466 741 811



www.2vv.cz



support@2vv.cz

