



PARTNER
IN VENTILATION
2VV.CZ

EN

AirGENIO^{2W} COMFORT



Operation instructions



1. CONTROL

READ CAREFULLY!

Before the initial commissioning, check:


- that the device is well fastened to the support structure,
- that the device is properly closed
- that the power supply is properly connected, including the earthing and the external trigger protection,
- that all the electrical components are securely connected,
- that the installation complies with all the instructions herein,
- that no tool or any other object that may damage the unit remains within.

ATTENTION!

- Interventions or changes to the internal connections are forbidden and shall result in the loss of warranty.
- We recommend the use of accessories supplied by our company. Contact your supplier in case of doubts regarding the use of non-original accessories.


START-UP

After connecting power supply, the display lights up and the data is loaded. The device is ready to be activated once the service data has fully loaded.



The remote control has a touch screen. The device is controlled tapping the symbols on the screen

Description of main screen




 The menus are described below

-  page 13    
-  page 14 
-  page 17 


Warning icons

They inform about errors. Clicking on them opens a screen with the error report.



Information icons

They only inform about status, not errors.



1. CONTROL



Current status

This screen displays detailed status of the shutter and sensor values:

- Current set air flow (step or %), informational icons
- Air temperature for intake*, exhaust*, room temperature*, and temperature outside the building* (* - in the event that the necessary sensors are installed and enabled)
- Set heater power (if included)

Exterior temperature: 16°C

Heater power: 50%

Blower power: 80%

Spatial temperature: 22°C

Return to previous screen


SP= required temperature: SP:45°C

Indication of heating blockage (summer mode)

Info

Information about unit type

If there are SLAVE shutters connected, the information from them is displayed here. Access to them is available by shifting the screen upward.



Sub 3: 0% 10% W:30°C 20°C

Sub 4: 10% 20% W:31°C 21°C

Sub 5: Off

Sub 6: 30% 40% W:33°C 23°C

Info



Settings can be found in these instructions in the "SUBUNITS" menu.



Settings MENU

Display backlight

Language

Date and time

Setting air flow (for closed doors)

Setting required temperature (for closed doors)

Timer

Return to previous screen

QR code

Parameters

15:11



Required temperature settings with closed doors

Required temperature on selected temperature sensor in 1616/Temperature sensor (ROOM, ROOM BMS)

21°C

23°C

Reducing or increasing required temperature

Required power

Manual mode = %

Automatic mode = °C

Confirm + return



In the event that heating is suspended by summer mode (MENU - SUMMER HEATING), the "Sun" icon is displayed here without the option to select power.



Air flow settings with closed doors

Display required air flow (three speeds)

Display the current air flow status

80%

20%

Reduce or increase opening's air flow (with closed doors)

Confirm + return

08:11

Fan

1. CONTROL



Required temperature settings with closed doors

In menu 34 Adv. Fan settings you can select if you want the fan to continue when the set point is reached or if you want the fan to stop. (Default)


When selecting this function the fan will stop when the set point for room temperature is reached. When its not selected the fan will always run.

Setting the time when the curtain will operate after the door is closed. Even when the set room temperature is reached


Annotations for menu 34:

- Minimum fan output for closed and open doors.
- Maximum fan performance for closed and open doors.

To activate this function, you need to select the room thermostat sensor in menu 09.



If this is not activated, the curtain will turn off immediately after the door is closed, but the desired temperature must be reached.



Date and time settings

Setting current date and time

Navigation arrows:


- Confirm + return
- Return to main screen

1. CONTROL




Timer

Unless otherwise set, the unit goes on stand-by mode after the timer expires.



Weekly mode




Tap on a day to set different time modes


Button to copy the day plan to another day



Annual mode




Tap to add a new time mode




Language

There are 5 languages available



Lightning settings




1. CONTROL




Service menu

Enter code 1616 to access the service menu



Delete/return


Access menu



Choose this menu after centring the screen and tapping on enter

Access selected menu

MENU - MODE



Select heating mode MANUAL / AUTOMATIC

Activate / deactivate automatic speed control.

Setting the difference between outdoor and indoor temperature.

Setting AUTO or MANUAL may block/unblock certain items in the service menu.


Manual: works according to the set heating / ventilation output

Automat: Heats automatically and trying to reach the desired temperature on the selected sensor (ROOM,BMS) the fan works according to the set performance. if it is not selected (Auto speed control)

Auto speed control: automatically regulates the fan's power on the basis of the difference temperature

MENU - HW SETTING

Use this menu to set the detailed behaviour of the inputs and outputs of the regulators



Door contact (NO/NC)

External control contact (NO/NC)

Error contact (NO/NC)

Ad 1)

Ad 2)

Ad 3)

Ad 1) - External temperature sensor activation/settings

None - no sensor is connected - inactive

EXT-1 (45,46) - sensor connected (must be on terminals 45 and 46)

BMS - temperature sensor active and used from the parent system

Ad 2) - Sets the external contact input behaviour. Options:

None - inactive

External control - External switching of device

Night reduction - Activation/deactivation of the night attenuation (settings described later in this manual)

Ad 3) - Thermostat (NO/NC)

MENU - FILTER TIMER

Use this menu to set the period (in motor hours) after which you will be reminded to replace the filters or reset to timer.




Set the time after which a notice will appear in the main screen.

1000h ~ 5000h

Current timer status

RESET button (use after replacing filters)


Shows the status of the clogged filter in the main screen



1. CONTROL


MENU - TEMPERATURE SENSOR

Available only in automatic mode
Use this menu to select the sensor to be used for primary temperature control



Options:
None
Room – Room temperature sensor
Room BMS – Room temperature sensor from master system

Available only in manual mode.



MENU - MODBUS RTU


Use this menu to set the Modbus RTU communication parameters



! An incorrect setting may prevent communication with the regulator

MENU - USER LOCK

Use this menu to set the limits to control the regulator with a multi-level panel




Options:
None – Limit inactive
On/Off – Only On/Off and access to the information menu are enabled in the main screen
On/Off, Temp, Flow – On/Off, the information menu, and temperature and air flow settings can be accessed without password.
Full – Only the information menu can be accessed without password
User mode – Special user mode, see image below




MENU - SUMMER HEATING

Use this menu to set heating limits in summer months
Winter mode set by default. Enabling the function allows heating also in summer



MENU - Night Reduction

This MENU allows for setting reduced temperatures during night hours with closed doors.



In this menu, the reduction of temperature may be set only by five degrees at the set time compared to the set (required) temperature.

1. CONTROL

MENU - DOOR CONTACT

This MENU allows for setting the behaviour of the regulator according to doors contact

Activation/de-activation of this function

Mode: **Fixed** - fixed setting
Selflearning - automation menu

Setting Fixed mode

Time interval

Blower power with open doors

Required temperature with open doors

Suspend mode: at a set time, or upon achieving a specific temperature

Time of shutter operation per minimum rotation of the motor from closed doors.

Time of shutter operation per maximum rotation of the motor from closed doors.

Temperature

Blower power with open doors.

The temperature the shutter attempts to reach with open doors.

In this menu it is possible to specify which sensor will be active and the temperature the shutter will attempt to reach after closing doors so as to balance temperature loss. After reaching the set temperature, the shutter transitions into the selected automatic/manual mode.

MENU Selflearning

Selflearning- available only in automation and active function mode (Auto speed control), depending on the number of open doors it optimises the period in which the shutter is in operation, even when doors are closed.

Must be set to activate Selflearning.

MENU - WATER ANTIFREEZE

The menu is enabled only in units with water exchanger


Setting the temperature to activate the heat exchanger protection.

The protection of the water exchanger is defined via the menu. If this function is not selected, the water heat exchanger protection is not activated.


1. CONTROL

MENU - SUBUNITS

Use this menu to set the behaviour of the IC-S regulators connected as SLAVE



Slave address parameter:




ADDRESS	SLAVE UNIT	ADDRESS	SLAVE UNIT
1	1	6	6
2	2	7	7
3	3	8	8
4	4	9	9
5	5	A	10

Ad 1) - Use one door contact as main. Its status will be sent to the SLAVE regulators and it will no longer be necessary to connect it to each regulator, if required.

- Not allowed = the door contact will not transmit to the SLAVE regulator from the MASTER
- Allowed = the door contact will transmit to the SLAVE regulator from the MASTER


Ad 2) - Activates in the main screen the icon to turn each SLAVE regulator ON/OFF. If inactive, all the SLAVE regulators will be turned on or off simultaneously

- Not allowed = The SLAVE regulators are turned on/off simultaneously
- Allowed = The SLAVE regulators can be turned on/off individually from the main screen



MENU - Adv. WATER SETTING

This MENU is available only for units with water heat exchanger. It allows for advanced setting of water heat exchanger regulation.




Setting period for valve movement. Only at 0:00 time and in Standby mode.

MENU - Adv. fan setting

The MENU for setting the blowers when closing and opening doors. It allows for advanced settings of blower control.

The time for which the blower will be operational from the moment the desired temperature is achieved +0.3°C on the ROOM sensor in closed door mode. This setting is available only when the ROOM regulation sensor is selected (1616/Temperature sensor)



Setting blower power limits for open doors. Min - Max


Setting blower power limits for closed doors. Min - Max

The set limits on blower power restrict the extent of blower control for open and closed doors. This restriction is applied to manual and automatic control of blower power. Exceeding limits in any blower power setting is signalled when the setting element turns red with the text overruns.

1. CONTROL

MENU - OTHER SETTINGS

Use this menu to set the remaining parameters




Ad 1) - Sets the CAN address of the control panel so up to 2 control panels may be connected to the MASTER regulator
 Options: CP 1 = control panel's address is 1
 CP 2 = control panel's address is 2


! ATTENTION!

Each panel must have its own address, otherwise it may result in the malfunction of the regulator.


Terminals must be set if multiple panels are to be connected. They are found in the main electronics and the controller:




Example of controller connection - Option 1:




Electric connection - Option 1:



Electric connection - Option 2:



Electric connection - Option 2:



MENU - FACTORY RESET

Use this to reset the default values



Press "FACTORY RESET" to reset the default values of MENU 1616



Once completed, we recommend to turn the main supply off and on.

2. MALFUNCTIONS

2.1 MALFUNCTIONS

Disconnect the main power supply before any intervention to the unit. If you are not sure of the correct steps, do not attempt to perform any repairs and call a professional service!

Description	Unit behaviour	Likely problem	Solution
44 – Fan error	Unit out of order	Overheated fan or defect on thermal contact of inlet fan	Determine the cause of the overheating (defective bearing, short-circuit...) or replace the motor.
45 – Mandatory maintenance/filter clogged	Unit operational	Filter clogged or the time to replace it has come	Replace filters. After replacing, do not forget to reset the MENU 1616 – FILTER TIMER
46 – Heater malfunction	Unit out of order	Heater malfunction	Check the heater and the condition of the safety thermostat Does the heater have proper cooling? Check engine running.
65 – Communication error	Unit out of order	Communication error	Check the communication cable for damages and if it is properly connected Observe the wiring diagram to prevent occurrences that may disrupt communication (wiring near high tension, phenomena on site causing disruptions)
Unit's not working	Unit out of order	Power supply interrupted	Check that the power supply is not interrupted
		Cracked fuse	Check the fuse in side the control module
The heating switches off automatically	Unit operational but not heating	The heater overheats	The heater overheats due to insufficient air flow. Check that the ventilators are in good order and that the air supply is not disrupted.

 **ATTENTION!**

Switch off the main power supply before any intervention inside the unit. Let the unit cool!

3. CONCLUSION

3.1. CONCLUSION

In case of any doubt or query, do not hesitate to contact our sales or technical support departments.



2VV, s.r.o.
Fáblovka 568
533 52 Pardubice
Czech Republic



+420 466 741 811



www.2vv.cz



support@2vv.cz

